

EVOLUTION DX2 • SHORT HAUL MODEM CONNECTIONS

CENTRAL COMPUTER

CONTROLLER

MAKE SURE THAT THE JUMPER IS SET FOR "JP1 EN" AND THE SWITCH IS SET TO "DCE" ON BOTH MODEMS

